

**MODEL 107 & 107B TEMPERATURE PROBES
INSTRUCTION MANUAL**

REVISION: 01/04/03

COPYRIGHT (c) 1983-2003 CAMPBELL SCIENTIFIC, INC.

WARRANTY AND ASSISTANCE

The **MODEL 107 & 107B TEMPERATURE PROBES** are warranted by CAMPBELL SCIENTIFIC (CANADA) CORP. ("CSC") to be free from defects in materials and workmanship under normal use and service for **twelve (12) months** from date of shipment unless specified otherwise. CSC's obligation under this warranty is limited to repairing or replacing (at CSC's option) defective products. The customer shall assume all costs of removing, reinstalling, and shipping defective products to CSC. CSC will return such products by surface carrier prepaid. This warranty shall not apply to any CSC products which have been subjected to modification, misuse, neglect, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for a particular purpose. CSC is not liable for special, indirect, incidental, or consequential damages.

Products may not be returned without prior authorization. To obtain a Return Merchandise Authorization (RMA), contact CAMPBELL SCIENTIFIC (CANADA) CORP., at (780) 454-2505. An RMA number will be issued in order to facilitate Repair Personnel in identifying an instrument upon arrival. Please write this number clearly on the outside of the shipping container. Include description of symptoms and all pertinent details.

CAMPBELL SCIENTIFIC (CANADA) CORP. does not accept collect calls.

Non-warranty products returned for repair should be accompanied by a purchase order to cover repair costs.



CAMPBELL SCIENTIFIC
C A N A D A C O R P .

11564 - 149 street - edmonton - alberta - T5M 1W7
tel 780.454.2505 fax 780.454.2655

www.campbellsci.ca

Model 107 & 107B Temperature Probes

1. General

The 107 Temperature Probe uses a thermistor to measure air temperature (107B for soil and water). Custom lead lengths are available up to 1000 ft.

For air temperature, a 41303 radiation shield is used to mount the 107 Probe and limit solar radiation loading. The 107B probe is designed to be buried or submerged in water to 200' (86 psi).

1.1 Specifications

Temperature

Measurement Range: -35° to $+50^{\circ}\text{C}$

Thermistor Inter-

changeability Error: Typically $<\pm 0.2^{\circ}\text{C}$ over 0°C to 60°C ; ± 0.4 @ -35°C

Temperature

Survival Range: -50°C to $+100^{\circ}\text{C}$

Polynomial

Linearization Error: $<\pm 0.5^{\circ}\text{C}$ over -35°C to $+50^{\circ}\text{C}$

Time Constant

In Air: Between 30 and 60 seconds in a wind speed of 5 m s^{-1}

NOTE

The black outer jacket of the 107 cable is Santoprene[®] rubber. This compound was chosen for its resistance to temperature extremes, moisture, and UV degradation. However, this jacket will support combustion in air. It is rated as slow burning when tested according to U.L. 94 H.B. and will pass FMVSS302. Local fire codes may preclude its use inside buildings. The 107B uses a different fire rated cable and does not support combustion in air.

2. Accuracy

The overall probe accuracy is a combination of the thermistor's interchangeability specification, the precision of the bridge resistors, and the polynomial error. In a "worst case" all errors add to an accuracy of $\pm 0.4^{\circ}\text{C}$ over the range of -24° to 48°C and $\pm 0.9^{\circ}\text{C}$ over the range of -38°C to 53°C . The major error component is the interchangeability specification of the thermistor, tabulated in Table 2-1. For the range of 0° to 50°C the interchangeability error is predominantly offset and can be determined with a single point calibration. Compensation can then be done with an offset entered in the measurement instruction. The bridge resistors are 0.1% tolerance with a 10 ppm temperature coefficient. Polynomial errors are tabulated in Table 2-2 and plotted in Figure 2-1.

TABLE 2-1. Thermistor Interchangeability Specification	
Temperature (°C)	Temperature Tolerance (±°C)
-40	0.40
-30	0.40
-20	0.32
-10	0.25
0 to +50	0.20

TABLE 2-2. Polynomial Error	
-40 to +56	<±1.0°C
-38 to +53	<±0.5°C
-24 to +48	<±0.1°C




FIGURE 2-1. Error Produced by Polynomial Fit to Published Values

3. Installation and Wiring

For air temperature measurement, the 107 must be housed inside a radiation shield when used outdoors. The 41303 Radiation Shield (see Figure 3-1) mounts to a CM6 or CM10 tripod. The UT018 mounting arm and UT6 Radiation Shield mount to a UT30 tower.

The standard lead length of 10 feet allow the 107 to be mounted at a 2 meter height on the CM6/CM10 tripod or the UT30 tower respectively.

When burying the 107B, insert the sensing head horizontally. Ensure that a “dew-loop” is created by dropping the cable lower than the sensor after

inserting it in the soil and before bringing the remainder of the lead to the surface. This prevents water from working down the cable and trying to work its way into the sensing head.

Connections to the datalogger for the 107 are shown in Figure 3-2 and Table 3-1.

The number of 107 probes per excitation channel is physically limited by the number of lead wires that can be inserted into a single excitation terminal (approximately 6).




FIGURE 3-1. 107 and 41303 Radiation Shield on a CM6/CM10 Tripod Mast




FIGURE 3-2. 107 & 107B Probe Datalogger Connections

Color	Function	CR10(X), CR510	21X, CR7, CR23X
Black	Excitation	Switched Excitation	Switched Excitation
Red	Signal	Single-Ended Channel	Single-Ended Channel
Purple	Signal Ground	AG	≡
Clear	Shield	G	≡

4. Programming

This section is for users who write their own datalogger programs. A datalogger program to measure this sensor can be created using Campbell Scientific’s Short Cut Program Builder software. You do not need to read this section to use Short Cut.

Instruction 11 is used to measure temperature. Instruction 11 provides AC excitation, makes a single ended voltage measurement, and calculates temperature with a fifth order polynomial. A multiplier of 1.0 and an offset of 0.0 yields temperature in Celsius. For Fahrenheit, use a multiplier of 1.8 and an offset of 32.

Color	Function	CR10(X)
Black	Excitation	Switched Ex Channel 3
Red	Signal	Single-Ended Channel 9
Purple	Signal Ground	AG
Clear	Shield	G

Example 1. Sample Program

1: Temp (107) (P11)		
1:	1	Reps
2:	9	SE Channel
3:	3	Excite all reps w/E3
4:	1	Loc [Air_Temp]
5:	1.0	Mult
6:	0.0	Offset

Excitation/Integration Codes

Code	Result
0x	excite all rep with channel x
1x	increment chan x with each rep
2x	excite all reps with channel x, 60 Hz rejection, 10 ms delay
3x	excite all reps with channel x, 50 Hz rejection, 10 ms delay
4x	increment chan x with each rep, 60 Hz rejection, 10 ms delay
5x	increment chan x with each rep, 50 Hz rejection, 10 ms delay

5. Maintenance and Calibration

The 107 & 107B Probes require minimal maintenance. Check monthly to make sure the radiation shield is free from debris.

For most applications it is unnecessary to calibrate the 107 & 107B to eliminate the thermistor offset. However, for those users that are interested, the following briefly describes calibrating the 107 & 107B probes.

A single point calibration can be performed to determine the 107 & 107B temperature offset (thermistor interchangeability). This calibration will not remove the polynomial error. The value of the offset must be chosen so that the probe outputs the temperature calculated by the polynomial, not the actual calibration temperature. For example, a 107 is placed in a calibration chamber that is at 0°C and the probe outputs 0.1°C. The offset is -0.16, because at 0°C the polynomial calculates a temperature of -0.06°C (Table 6-1).

6. Instruction 11 Details

Understanding the details in this section are not necessary for general operation of the 107 & 107B Probes with Campbell Scientific dataloggers.

Instruction 11 outputs a precise 2 VAC excitation (4 V with the 21X) and measures the voltage drop due to the sensor resistance (Figure 6-1). The thermistor resistance changes with temperature. Instruction 11 calculates the ratio of voltage measured to excitation voltage (V_s/V_x) which is related to resistance, as shown below:

$$V_s/V_x = 1000/(R_s+249000+1000)$$

where R_s is the resistance of the thermistor.

See the measurement section of the datalogger manual for more information on bridge measurements.

Instruction 11 then calculates temperature using a fifth order polynomial equation correlating V_s/V_x with temperature. The polynomial coefficients are given in Table 6-2. The polynomial input is $(V_s/V_x)*800$. Resistance and datalogger output at several temperatures are shown in Table 6-1.

**TABLE 6-1. Temperature, Resistance,
and Datalogger Output**

Temperature °C	Resistance OHMS	Output °C
-40.00	4067212	-39.18
-38.00	3543286	-37.55
-36.00	3092416	-35.83
-34.00	2703671	-34.02
-32.00	2367900	-32.13
-30.00	2077394	-30.18
-28.00	1825568	-28.19
-26.00	1606911	-26.15
-24.00	1416745	-24.11
-22.00	1251079	-22.05
-20.00	1106485	-20.00
-18.00	980100	-17.97
-16.00	869458	-15.95
-14.00	772463	-13.96
-12.00	687276	-11.97
-10.00	612366	-10.00
-8.00	546376	-8.02
-6.00	488178	-6.05
-4.00	436773	-4.06
-2.00	391294	-2.07
0.00	351017	-0.06
2.00	315288	1.96
4.00	283558	3.99
6.00	255337	6.02
8.00	230210	8.04
10.00	207807	10.06
12.00	187803	12.07
14.00	169924	14.06
16.00	153923	16.05
18.00	139588	18.02
20.00	126729	19.99
22.00	115179	21.97
24.00	104796	23.95
26.00	95449	25.94
28.00	87026	27.93
30.00	79428	29.95
32.00	72567	31.97
34.00	66365	33.99
36.00	60752	36.02
38.00	55668	38.05
40.00	51058	40.07
42.00	46873	42.07
44.00	43071	44.05
46.00	39613	46.00
48.00	36465	47.91
50.00	33598	49.77
52.00	30983	51.59
54.00	28595	53.35
56.00	26413	55.05
58.00	24419	56.70
60.00	22593	58.28




FIGURE 6-1. 107 & 107B Thermistor Probe Schematic

Coefficient	Value
C0	-53.4601
C1	90.807
C2	-83.257
C3	52.283
C4	-16.723
C5	2.211

7. Electrically Noisy Environments

AC power lines can be the source of electrical noise. If the datalogger is in an electronically noisy environment, the 107 temperature measurement should be measured with 60 Hz rejection. Sixty and 50 Hz rejection is available as an option in the Excitation Channel parameter of Instruction 11 for the CR10X, CR510, and CR23X dataloggers. For the CR10, CR21X and CR7, the 107 should be measured with the AC half bridge (Instruction 5).

Example 2. Sample CR10(X) Instructions Using AC Half Bridge

1: AC Half Bridge (P5)		
1:	1	Reps
2:	22	7.5 mV 60 Hz Rejection Range
3:	9	SE Channel
4:	3	Excite all reps w/Exchan 3
5:	2000	mV Excitation ;Use 4000 mV on 21X and CR7
6:	1	Loc [Air_Temp]
7:	800	Mult
8:	0	Offset

```

2: Polynomial (P55)
1:      1      Reps
2:      1      X Loc [ Air_Temp ]
3:      1      F(X) Loc [ Air_Temp ]
4:     -53.46   C0
5:      90.807  C1
6:     -83.257  C2
7:      52.283  C3
8:     -16.723  C4
9:       2.211  C5
    
```

8. Long Lead Lengths

The 60 and 50 Hz rejection options for the CR10X, CR510, and CR23X include a delay to accommodate long lead lengths. For the CR10, 21X, and CR7, if the 107 has lead lengths of more than 300 feet, use the DC Half Bridge instruction (Instruction 4) with a 2 millisecond delay to measure temperature. The delay provides a longer settling time before the measurement is made. Do not use the 107 or 107B with long lead lengths in an electrically noisy environment.

Example 3. Sample Program CR10 Using DC Half Bridge with Delay

```

1: Excite-Delay (SE) (P4)
1:      1      Reps
2:      2      7.5 mV Slow Range
3:      9      SE Channel
4:      3      Excite all reps w/Exchan 3
5:      2      Delay (units 0.01 sec)
6:     2000    mV Excitation ;Use 4000 mV on 21X and CR7
7:      1      Loc [ Air_Temp ]
8:      .4     Mult ;Use 0.2 on 21X and CR7
9:      0      Offset

2: Polynomial (P55)
1:      1      Reps
2:      1      X Loc [ Air_Temp ]
3:      1      F(X) Loc [ Air_Temp ]
4:     -53.46   C0
5:      90.807  C1
6:     -83.257  C2
7:      52.283  C3
8:     -16.723  C4
9:       2.211  C5
    
```